

FUNTEC

How to set up the FUNTEC Competition Net:

1. Pretension:

As a first step the net will be attached to the tackle system. Please hook the loop of the upper tensioning rope (that side WITHOUT the thick black rope attached) into the snap hook (see fig.1). Go to the other post and put the thick black rope over the pulley. Pull it down and stick it to one of the hooks of the tensioning system of the post (see fig.2). The net tension should already be very high now.




fig.1

2. Tension:

Pull down the rope of the tackle in order to achieve a high tension of the upper netband. Press the loose tackle rope into the rope brake of the black block.

3. Centring the net:

Centre the net with the help of the red ropes that come from the eyes at the top corners of the net. Use the little white bars which you find directly underneath the pulleys (see arrows at fig.1 and 2). ATTENTION: It is essential to dismantle the ropes for the net centring BEFORE loosening the total net.

4. Fastening the bottom netband:

Both ends of the white rope in the bottom netband have to be knotted to a firm loop. Take the red rope and pull it from the lower single hook at the post back to the white loop. Put it through the loop and tighten it towards the post. Now fix it with a knot. It might be helpful to manage this simultaneously with two persons at both ends of the white rope. Otherwise you have to adjust one side after the other probably more than once. Now the net is fixed to the posts at the top and the bottom. It is centred between the posts and you can move the bottom netband on the white rope. Use this effect to adjust the sides of the net exactly upright.




fig.2

Requirements for this manual:

The FUNTEC competition net must be designed for the use with stationary posts.

The FUNTEC competition net is used with FUNTEC stationary posts.